


TXL Welcome on board



# ONLINE VERSION

- **DE** Du findest diese Anleitung in Deiner Sprache auch online: www.hauptstadtkoffer.de/de/downloads/txl-koffer
- **EN** You will find this manual in your language also online: www.hauptstadtkoffer.de/en/downloads/txl-koffer
- FR Vous pouvez trouver en ligne les instructions dans votre langue: www.hauptstadtkoffer.de/fr/downloads/txl-koffer
  - **ES -** Encontrará las instrucciones en su idioma también en línea: www.hauptstadtkoffer.de/es/downloads/txl-koffer
    - IT Puoi trovare on-line questo manuale nella tua lingua: www.hauptstadtkoffer.de/it/downloads/txl-koffer

# **CONTENTS**

About the Product
Tips und Tricks
TSA Combination Lock
Telescopic Handle and Wheels
For the Start of your Trip

Customer Service +49(0) 30.63 413 414 | Mon. - Fri.: 9.00 - 16.00 info@hauptstadtkoffer.de





**HAUPTSTADTKOFFER®** 

www.hauptstadtkoffer.de

# THANK YOU FOR CHOOSING A HAUPTSTADTKOFFER!

Congratulations: you have selected a top-class product that meets the highest quality standards.

#### ADVANTAGES OF A PP HARDSHELL

The matte surface of Polypropylene gives the trolley its noble finish.

This lightweight and dimensionally stable hardshell is particularly unbreakable, shock- and impact-resistant. In addition, the matte surface is extremely resistant to scratches and fingerprints.

**5 YEAR** Guarantee

Five-year guarantee from the date of purchase, subject to guarantee conditions. More info at: hauptstadtkoffer.de/de/garantie



Especially lightweight for convenient transportation



Four 360° easy-running wheels



Easy-to-replace parts. attached by screws



TSA lock with selectable number combination



Extra seal for zips protection against moisture



Telescopic handle with a push-button to select the height level

## TIPS AND TRICKS



# **Avoid surprises**

*More security.* A bag belt<sup>1</sup> protects your luggage. Reduce excess luggage. With the mobile luggage scales.1 you can avoid additional costs. No more scratches. A suitcase cover¹ protects your case during rough baggage transportation at the airport.

# Organised packing



More organised. The cross-belt keeps your luggage together. The intermediate floor with two separate compartments helps you gain an overview when packing. Chaos in the suitcase. With an organiser set<sup>1</sup>, you can keep your suitcase tidier. Too much luggage. A foldable travel bag1 is the perfect solution for excess luggage.



Enjoy a pleasant travel experience Set off on your holiday relaxed. A neck pillow<sup>1</sup> protects against tension by allowing an anatomically-correct reclined position. Sleep peacefully. A sleep mask1 gives you a darker environment and ensures a peaceful night's sleep.

# How to care for your HAUPTSTADTKOFFER correctly.

Clean any dirt on the outer shell with a damp cotton cloth. Treat small scratches with polish and a cotton cloth. When storing, wrap the outer shell of the suitcase in a fabric or suitcase cover<sup>1</sup>.

2

<sup>1</sup> You can find useful travel accessories in the online shop: www.hauptstadtkoffer.de/de/zubehoer

# ALL YOU NEED TO KNOW ABOUT YOUR TSA COMBINATION LOCK

# Why do I need a TSA combination lock?

TSA locks are recommended for travel in the USA. The item of luggage can be opened and searched by airport security staff with a master key, without damaging the lock.





## INSTRUCTIONS FOR THE TSA COMBINATION LOCK

Set a personal number combination:

- 1. (b) Set the wheels to the number combination 0-0-0.
- 2. (a) Press the button using a sharp object until you hear a "click".
- 3. (b) Turn the wheels to set your own number combination.
- 4. (c) Press the button until you hear the "click" again.
- 5. To open the lock, press the button (c) in the direction of the arrow. Repeat steps 1-4 if you need to change the combination, but with a different number combination.



More info: www.hauptstadtkoffer.de/de/kofferschloss



## Where is the key for the TSA lock?

Only airport security personnel possess the master key for the TSA lock. For this reason, you do not require a key for your TSA lock – just a number combination. Suitcase manufacturers and retailers do not possess a TSA key.




#### Forgotten your number combination?

If you forget your number combination, you can open your suitcase in the following way: a 3-digit number lock has 999 different combinations. If you try out all possible combinations (beginning with 0-0-0), you will be able to open the lock in approx. 20-30 minutes.

If you have any problems/queries regarding your product, please contact our customer service




+49(0) 30.63 413 414 | info@hauptstadtkoffer.de



# SUSTAINABLE FUNCTIONALITY




Your suitcase is made from components that are easily replaced and screw into place. Parts such as the telescopic handle/wheels are simple to replace.





- 1. Open the zip of the interior lining in the suitcase (fig. 1).
- 2. Remove the protective film on the screws (fig. 2).
- 3. The screws (quantity: 6) can be loosened with a Phillips screwdriver (fig. 2).
- 4. Remove the defective telescopic handle above the suitcase (you may experience some resistance, so employ a little strength to remove it) and substitute this with a new handle.

If sensitive parts, such as the telescopic handle or wheels, stop functioning optimally after several years of use, please get in touch with our customer service team.



+49(0) 30.63 413 414 | info@hauptstadtkoffer.de

## CHANGING THE WHEELS

- 1. Open the zip of the interior lining of the suitcase (fig. 1).
- 2. Remove the protective film from the screws (fig. 2).
- 3. The screws (quantity: 8) can be loosened with a Phillips screwdriver (fig. 2).
- 4. Remove the defective wheels and substitute with new wheels.

More info in the video: hauptstadtkoffer.de/koffer-videos



# TO-DO LIST



1. Set the number combination



2. Pack the case



3. Check your packing list



4. Enjoy your holiday



5. Review your suitcase

## YOUR EVALUATION IS IMPORTANT TO US



We would be delighted if you would share your experience with this product. Your evaluation helps other customers make a purchase decision and also provides us with valuable feedback.

If there is a problem with your delivery, please get in touch with our customer service team, so that we can resolve the problem as quickly as possible.

8

# YOUR PACKING LIST



# Clothing

- Underwear, pyjamas or night-shirt
- Swimwear
- Sports clothing
- Trainers
- Rain clothing or umbrella



#### **Documents**

- Passport
- Travel tickets
- Credit cards
- Driving licence or driving papers
- Emergency pass



# **Hygiene & Cosmetics**

- Toothbrush and toothpaste
- Shampoo and shower gel
- Shaving equipment
- Make-up equipment, face creams etc.
- Contact lens solution and containers
- Medicines
- Sun cream



#### **Electronics**

- Adaptor plug for foreign sockets
- Camera and charging equipment
- Photography equipment, video camera
- Memory cards
- Hair dryer
- Travel alarm
- MP3 player
- Batteries
- Torch

**,** 



**HAUPTSTADTKOFFER®** www.hauptstadtkoffer.de